



INSTRUCTIONS FOR WOLFKATZ MR2 BIG BRAKE KIT STAGE II WILWOOD CALIPER TEMPLATE:

- 1) CUT AROUND BLACK OUTLINE. TRACE ONTO CARDBOARD. CUT OUT CARDBOARD.
- 2) PLACE INTO WHEEL AS SHOWN
- 3) BE SURE WHEEL SPOKES DON'T HIT WHERE IT SAYS "THIS NEEDS TO CEAR YOU RIM."
- 4) IF OUTER BLACKE LINE HITS, SUPERLITE CALIPER NEEDS SPACER TO WORK. TRIM FOR DYNAPRO IF INTERESTRED IN SMALLER CALIPER.
- 5)DASHED LINES SHOW ADDITONAL CLEARANCE CREATED BY USING DYNAPRO CALIPER.