



NOTES:

- 1) DIMENSIONS FOR REFERENCE ONLY
- 2) PAY SPECIAL ATTENTION TO THE BOLD LINES.

INSTRUCTIONS FOR WOLFKATZ MR2 BIG BRAKE KIT STAGE II WILWOOD REAR PARKING BRAKE CALIPER TEMPLATE:

- 1) CUT AROUND BLACK OUTLINE. TRACE ONTO CARDBOARD. CUT OUT CARDBOARD. BE SURE TO PRINT TO SCALE!!!! CHECK WITH RULER.
- 2) PLACE INTO WHEEL AS SHOWN
- 3) BE SURE WHEEL SPOKES DON'T HIT WHERE IT SAYS "THIS NEEDS TO CLEAR YOUR RIM."
- 4) IF OUTER BLACK LINE HITS, WHEEL SPACER NEEDED TO WORK.
- 5) SHADED AREA CAN BE FILED / GROUND DOWN TO CREATE EXTRA CLEARANCE. BEWARE OF STICK ON WHEEL WEIGHTS! I HAD TO MOVE MINE SLIGHTLY TO MAKE FIT.

CUT SHADED AREA IF GRINDING E-BRAKE BRACKET COULD HELP

THIS TEMPLATE PORTION NEEDS TO CLEAR YOUR RIM.

STICK THIS IN YOUR WHEEL CENTER HOLE

WHEEL TO ROTOR / HUB MOUNTING PLANE

APPROXIMATE LOCATION OF OUTER ROTOR BRAKING SURFACE

